

Modbus RTU/TCP

COMPACT sizes 02-03,

program version 1.00 and newer versions

Overview

ModBus can access single addresses or multiple addresses simultaneously; either reading or writing single bit values or 16-bit values.

A ModBus address contains either a 1-bit discrete value or a 16-bit integer value.

Modbus Data formats

Modbus data types are 1-bit values and 16-bit values.

| Modbus Type | Description | Reference |
|------------------|------------------------|-----------|
| Coil Status | Discrete Output | 0x |
| Input Status | Discrete Input | 1x |
| Holding Register | 16 bit Output Register | 4x |
| Input Register | 16 bit Input Register | 3x |

Supported Modbus commands

The COMPACT air handling unit supports these ModBus commands.

| Function Code | Description. |
|---------------|--------------------------------------------------------------------|
| 01 | Read Coil Status |
| 02 | Read Input Status |
| 03 | Read Holding Registers |
| 04 | Read Input Registers |
| 05 | Force Single Coil |
| 06 | Preset Single Register |
| 08 | Diagnostics. Sub-function 00 Only - Return Query Data (loop back). |
| 15 | Force multiple coils |
| 16 | Preset Multiple Registers |

Coil Status. 1 bit (R/W).

| Modbus | Name | Min/Max | Misc |
|--------|----------------------------------------------------------------------------------------------------------|---------|------|
| 0x0001 | alarm reset | 0-1 | |
| | Resets tripped alarms. | | |
| 0x0002 | Reserve | | |
| | | | |
| 0x0003 | Reserve | | |
| | | | |
| 0x0004 | R.HX. Defrost func. | 0-1 | |
| | Setting for activating the defrost function for the rotary heat exchanger. 0= Inactive. 1= Active. | | |
| 0x0005 | Reserve | | |
| | | | |
| 0x0006 | Reserve | | |
| | | | |
| 0x0007 | Reserve | | |
| | | | |
| 0x0008 | Cool operation mode | 0-1 | |
| | Setting for cooling between off and auto operation. 0= Inactive. 1= Auto operation. | | |
| 0x0009 | Int. Night heat func. | 0-1 | |
| | Setting for activating the intermittent night heat function. 0= Inactive. 1= Active. | | |
| 0x0010 | Damper func. | 0-1 | |
| | Setting for activating the damper output relay during int. night heat. 0= Inactive. 1= Active. | | |
| 0x0011 | Summer night cooling | 0-1 | |
| | Setting for activating the summer night cool function. 0= Inactive. 1= Active. | | |
| 0x0012 | Reserve | | |
| | | | |
| 0x0013 | Outdoor temp compensation | 0-1 | |
| | Setting for activating the outdoor temperature compensation function. 0= Inactive. 1= Active. | | |
| 0x0014 | Outdoor airflow compensation | 0-1 | |
| | Setting for activating the outdoor airflow compensation function. 0= Inactive. 1= Active. | | |
| 0x0015 | Auto. Summer/winter switch | 0-1 | |
| | Setting for activating the automatic switch between summer/winter time function. 0= Inactive. 1= Active. | | |
| 0x0016 | Switch clock func. | 0-1 | |
| | Setting for switch clock function type. 0=Stop - low speed - high speed. 1=Low speed - high speed. | | |
| 0x0017 | Internal fire alarm func. | 0-1 | |
| | Setting for activating the internal fire alarm function. 0= Inactive. 1= Active. | | |

| | | | |
|--------|-------------------------------------------------------------------------------------------------------------------|-----|--|
| 0x0018 | Reserve | | |
| 0x0019 | External alarm 1 active at closure | 0-1 | |
| | Setting for external alarm number 1 condition to be activated. 0=Alarm at closed input. 1=Alarm at open input. | | |
| 0x0020 | External alarm 2 active at closure | 0-1 | |
| | Setting for external alarm number 2 condition to be activated. 0=Alarm at closed input. 1=Alarm at open input. | | |
| 0x0021 | Reserve | | |
| 0x0022 | Reserve | | |
| 0x0023 | Reserve | | |
| 0x0024 | External fire alarm func. | 0-1 | |
| | Setting for external fire resetting function. 0=Manual. 1=Automatic. | | |
| 0x0025 | External alarm 1 func. | 0-1 | |
| | Setting for external alarm 1 resetting function. 0=Manual. 1=Automatic. | | |
| 0x0026 | External alarm 2 func. | 0-1 | |
| | Setting for external alarm 2 resetting function. 0=Manual. 1=Automatic. | | |
| 0x0027 | Reserve | 0-1 | |
| 0x0028 | Reserve | 0-1 | |
| 0x0029 | Morningboost damper func. | 0-1 | |
| | Setting for activating the morningboost damper function. 0= Inactive. 1= Active. | | |
| 0x0030 | Morningboost extract func. | 0-1 | |
| | Setting for activating the morningboost extract air fan function. 0= Inactive. 1= Active. | | |
| 0x0031 | Filter func. | 0-1 | |
| | Setting for filter between calculated and pressure sensors. 0=Calculated. 1=Pressure sensors. | | |
| 0x0032 | Iqnomiq Plus module no.6 Cooling | 0-1 | |
| | Setting for activating Iqnomiq Plus no.6 Cooling module. 0=Inactive. 1=Active. | | |
| 0x0033 | Airing auto func. | 0-1 | |
| | Setting for activating the airing auto function. 0=Inactive. 1=Active. | | |

Input Status. 1 bit (RO).

| Modbus | Name | Min/Max | Misc |
|--------|-----------------------------------|---------|------|
| 1x0001 | Heat output | 0-1 | |
| | Status for relay output. | | |
| 1x0002 | Cool output 1 | 0-1 | |
| | Status for relay output. | | |
| 1x0003 | Cool output 2 | 0-1 | |
| | Status for relay output. | | |
| 1x0004 | Low speed output | 0-1 | |
| | Status for relay output. | | |
| 1x0005 | High speed output | 0-1 | |
| | Status for relay output. | | |
| 1x0006 | A-alarm. | 0-1 | |
| | Status for relay output. | | |
| 1x0007 | B-alarm. | 0-1 | |
| | Status for relay output. | | |
| 1x0008 | Operation output | 0-1 | |
| | Status for relay output. | | |
| 1x0009 | Damper output | 0-1 | |
| | Status for relay output. | | |
| 1x0010 | External low speed input | 0-1 | |
| | Status for digital input. | | |
| 1x0011 | External high speed input | 0-1 | |
| | Status for digital input. | | |
| 1x0012 | External alarm 1 input | 0-1 | |
| | Status for digital input. | | |
| 1x0013 | External alarm 2 input | 0-1 | |
| | Status for digital input. | | |
| 1x0014 | External fire alarm input. | 0-1 | |
| | Status for digital input. | | |
| 1x0015 | External stop input | 0-1 | |
| | Status for digital input. | | |
| 1x0016 | DIP Switch 1 | 0-1 | |
| | Status for dip switch setting. | | |
| 1x0017 | DIP Switch 2 | 0-1 | |
| | Status for dip switch setting. | | |
| 1x0018 | DIP Switch 3 | 0-1 | |
| | Status for dip switch setting. | | |
| 1x0019 | DIP Switch 4 | 0-1 | |
| | Status for dip switch setting. | | |
| 1x0020 | DIP Switch 5 | 0-1 | |
| | Status for dip switch setting. | | |
| 1x0021 | DIP Switch 6 | 0-1 | |
| | Status for dip switch setting. | | |
| 1x0022 | Reserve | | |
| | | | |

| | | | |
|--------|------------------------------------|-----|--|
| 1x0023 | Reserve | | |
| 1x0024 | Reserve | | |
| 1x0025 | R.HX rotation monitor | 0-1 | |
| | Status from the rotation detector. | | |
| 1x0026 | Reserve | | |
| 1x0027 | Reserve | | |
| 1x0028 | Reserve | | |
| 1x0029 | Pre-heat output | 0-1 | |
| | Status for relay output. | | |
| 1x0030 | Recirculation output | 0-1 | |
| | Status for relay output. | | |
| 1x0031 | Booster output | 0-1 | |
| | Status for relay output. | | |
| 1x0032 | Reserve | | |
| 1x0033 | Reserve | | |
| 1x0034 | Reserve | | |
| 1x0035 | Reserve | | |
| 1x0036 | Reserve | | |
| 1x0037 | Reserve | | |
| 1x0038 | Reserve | | |
| 1x0039 | Reserve | | |
| 1x0040 | Reserve | | |
| 1x0041 | Reserve | | |
| 1x0042 | Reserve | | |
| 1x0043 | Reserve | | |
| 1x0044 | Reserve | | |
| 1x0045 | Reserve | | |

| | | | |
|---------------------|---------------------------------------|-----|--|
| 1x0046 | Reserve | | |
| | | | |
| 1x0047 | Reserve | | |
| | | | |
| 1x0048 | Reserve | | |
| | | | |
| 1x0049 | Alarm number 1 | 0-1 | |
| | Status if alarm number 1 is active. | | |
| 1x0050 | Alarm number 2 | 0-1 | |
| | Status if alarm number 2 is active. | | |
| 1x0051 | Alarm number 3 | 0-1 | |
| | Status if alarm number 3 is active. | | |
| 1x0052 ...1x0247 | ... | | |
| | ... | | |
| 1x0248 | Alarm number 200 | 0-1 | |
| | Status if alarm number 200 is active. | | |
| 1x0249 | Info number 1 | 0-1 | |
| | Status if info number 1 is active. | | |
| 1x0250 | Info number 2 | 0-1 | |
| | Status if info number 2 is active. | | |
| 1x0251 | Info number 3 | 0-1 | |
| | Status if info number 3 is active. | | |
| 1x0252 ...1x0347 | ... | | |
| | ... | | |
| 1x0348 | Info number 100 | 0-1 | |
| | Status if info number 100 is active. | | |

Input Registers. 16-bit integer value (RO).

| Modbus | Name | Min/Max | Misc |
|--------|----------------------------------------------------------|-----------|------|
| 3x0001 | SA Airflow | 0-360l/s | |
| | Present supply airflow. | | |
| 3x0002 | SA Airflow regulator | 0-360l/s | |
| | Present supply airflow regulator setpoint. | | |
| 3x0003 | EA Airflow | 0-360l/s | |
| | Present extract airflow. | | |
| 3x0004 | EA Airflow regulator | 0-360l/s | |
| | Present extract airflow regulator setpoint. | | |
| 3x0005 | SA Duct pressure | 0-750Pa | |
| | Present supply air duct pressure. | | |
| 3x0006 | SA Duct pressure regulator | 0-750Pa | |
| | Present supply air duct pressure regulator setpoint. | | |
| 3x0007 | EA Duct pressure | 0-750Pa | |
| | Present extract air duct pressure. | | |
| 3x0008 | EA Duct pressure regulator | 0-750Pa | |
| | Present extract air duct pressure regulator setpoint. | | |
| 3x0009 | Reserve | | |
| | | | |
| 3x0010 | SA VAV demand regulator | 0-100.00% | |
| | Present supply air VAV demand regulator setpoint. | | |
| 3x0011 | Reserve | | |
| | | | |
| 3x0012 | EA VAV demand regulator | 0-100.00% | |
| | Present supply air VAV demand regulator setpoint. | | |
| 3x0013 | SA Fan level | 0-100.00% | |
| | Present running level for the supply air fan. | | |
| 3x0014 | EA Fan level | 0-100.00% | |
| | Present running level for the extract air fan. | | |
| 3x0015 | SA Fan effect | 0-500W | |
| | Present power consumption level for the supply air fan. | | |
| 3x0016 | EA Fan effect | 0-500W | |
| | Present power consumption level for the extract air fan. | | |
| 3x0017 | SFP | 0.0-9.9 | |
| | SFP supply air + extract air. | | |
| 3x0018 | Reserve | | |
| | | | |
| 3x0019 | Reserve | | |
| | | | |
| 3x0020 | SA Voltage | 0-500V | |
| | Present voltage level for the supply air fan. | | |
| 3x0021 | EA Voltage | 0-500V | |
| | Present voltage level for the extract air fan. | | |
| 3x0022 | SA Current | 0-2.000A | |
| | Present current level for the supply air fan. | | |

| | | | |
|---------------|----------------------------------------------------------------------------|--------------|--|
| 3x0023 | EA Current | 0-2.000A | |
| | Present current level for the extract air fan. | | |
| 3x0024 | SA Airflow pressure | 0-3000Pa | |
| | Present airflow pressure in the supply air fan inlet. | | |
| 3x0025 | EA Airflow pressure | 0-3000Pa | |
| | Present airflow pressure in the extract air fan inlet. | | |
| 3x0026 | SA Temp regulator | 5.00-60.00°C | |
| | Present supply air temperature regulator setpoint. | | |
| 3x0027 | EA Temp regulator | 5.00-40.00°C | |
| | Present extract air temperature regulator setpoint. | | |
| 3x0028 | SA Temperature | 5.00-40.00°C | |
| | Present supply air temperature. | | |
| 3x0029 | EA/Room temperature | 5.00-40.00°C | |
| | Present extract air/room temperature in the unit. | | |
| 3x0030 | Outdoor temperatur | 5.00-40.00°C | |
| | Present outdoor air temperature in the unit. | | |
| 3x0031 | EA/Room temperature (external) | 5.00-40.00°C | |
| | Present room temperature external from the unit. | | |
| 3x0032 | Outdoor temperatur (external) | 5.00-40.00°C | |
| | Present outdoor air temperature external from the unit. | | |
| 3x0033 | Anti frost temperature | 5-40.00°C | |
| | Present anti frost temperature for water reheating coils. | | |
| 3x0034 | Reserve | | |
| | | | |
| 3x0035 | Reserve | | |
| | | | |
| 3x0036 | R. Heat exchange level | 0-100.00% | |
| | Present operation level from rotary heat exchange. | | |
| 3x0037 | Reheat level | 0-100.00% | |
| | Present level of reheat. | | |
| 3x0038 | SA Down regulation level | 0-100.00% | |
| | Present level of supply airflow down regulation. | | |
| 3x0039 | Reserve | | |
| | | | |
| 3x0040 | Cooling level | 0-100.00% | |
| | Present level of cooling. | | |
| 3x0041 | Heating boost level | 0-100.00% | |
| | Present level of heating boost. | | |
| 3x0042 | Cooling boost level | 0-100.00% | |
| | Present level of cooling boost. | | |
| 3x0043 | HX pressure level | 0-1000Pa | |
| | Present pressure drop for the rotary heat exchanger. | | |
| 3x0044 | HX pressure alarm limit | 0-1000Pa | |
| | Present pressure drop alarm limit for the rotary heat exchanger. | | |
| 3x0045 | HX temperature | 0-100.00°C | |
| | Present temperature inside the control unit for the rotary heat exchanger. | | |

| | | | |
|---------------|------------------------------------------------------------------------------------------------|---------------|--|
| 3x0046 | Effect reduction level | 0-100.00% | |
| | Present level of max output signal for electrical reheaters, active during low supply airflow. | | |
| 3x0047 | Anti frost temp setpoint/operation | 10.00-16.00°C | |
| | Present anti frost temperature setpoint for water reheating coils during unit operation. | | |
| 3x0048 | Anti frost temp setpoint/stop | 15.00-40.00°C | |
| | Present anti frost temperature setpoint for water reheating coils when the unit is in stop. | | |
| 3x0049 | Anti frost temp alarm limit | 5.00-30.00°C | |
| | Setting of antifrost temperature alarm limit. | | |
| 3x0050 | Supply air filter pressure level | 0-3000Pa | |
| | Present supply air filter pressure drop. | | |
| 3x0051 | Supply air filter pressure alarm limit. | 0-1000Pa | |
| | Present supply air filter pressure alarm limit. | | |
| 3x0052 | Supply air filter pressure level, new | 0-1000Pa | |
| | Supply air filter pressure saved from calibration. | | |
| 3x0053 | Extract air filter pressure level | 0-3000Pa | |
| | Present extract air filter pressure drop. | | |
| 3x0054 | Extract air filter pressure alarm limit. | 0-1000Pa | |
| | Present extract air filter pressure alarm limit. | | |
| 3x0055 | Extract air filter pressure level, new | 0-1000Pa | |
| | Extract air filter pressure saved from calibration. | | |
| 3x0056 | Reserve | | |
| | | | |
| 3x0057 | Coil type | 0-20 | |
| | Present connected reheat coil type. | | |
| 3x0058 | Cool step time | 0-600s | |
| | Present time between cool step shift. | | |
| 3x0059 | Cool relay 1 restart time | 0-1800s | |
| | Present time between two starts of cool relay 1. | | |
| 3x0060 | Cool relay 2 restart time | 0-1800s | |
| | Present time between two starts of cool relay 2. | | |
| 3x0061 | Programversion, HMI | 0-10.00 | |
| | Present programversion for the handterminal. | | |
| 3x0062 | Programversion, HMI-slave | 0-10.00 | |
| | Present programversion for the extra handterminal. | | |
| 3x0063 | Programversion, main controller. | 0-10.00 | |
| | Present programversion for the main control unit. | | |
| 3x0064 | Programversion, SA FC-1. | 0-10.00 | |
| | Present programversion for the supply air frequency converter no.1. | | |
| 3x0065 | Programversion, SA FC-2. | 0-10.00 | |
| | Present programversion for the supply air frequency converter no.2. | | |
| 3x0066 | Programversion, EA FC-1. | 0-10.00 | |
| | Present programversion for the extract air frequency converter no.1. | | |
| 3x0067 | Programversion, EA FC-2. | 0-10.00 | |
| | Present programversion for the extract air frequency converter no.2. | | |

| | | | |
|---------------|------------------------------------------------------------------------------------------------|---------|--|
| 3x0068 | Programversion, HX control unit | 0-10.00 | |
| | Present programversion for the rotary heat exchange control unit. | | |
| 3x0069 | Weekday | 0 - 6 | |
| | Present weekday for the unit's internal clock. | | |
| 3x0070 | Extended low speed op. Hours | 0-23 | |
| | Present time for extended low speed operation. | | |
| 3x0071 | Extended low speed op. Minutes | 0-59 | |
| | Present time for extended low speed operation. | | |
| 3x0072 | Extended high speed op. Hours | 0-23 | |
| | Present time for extended high speed operation. | | |
| 3x0073 | Extended high speed op. Minutes | 0-59 | |
| | Present time for extended high speed operation. | | |
| 3x0074 | SA Fan operation time | 0-9999 | |
| | Present operation time for the supply air fan, measured in minutes and present in days (24h). | | |
| 3x0075 | EA Fan operation time | 0-9999 | |
| | Present operation time for the extract air fan, measured in minutes and present in days (24h). | | |
| 3x0076 | Cool operation time | 0-9999 | |
| | Present operation time for cooling, measured in minutes and present in days (24h). | | |
| 3x0077 | Heat exchange operation time | 0-9999 | |
| | Present operation time for heat exchange, measured in minutes and present in days (24h). | | |
| 3x0078 | Reheat operation time | 0-9999 | |
| | Present operation time for reheat, measured in minutes and present in days (24h). | | |
| 3x0079 | Present tripped alarm | 0-200 | |
| | Present tripped alarm number with highest priority. | | |
| 3x0080 | Active not tripped alarm no.1 | 0-200 | |
| | Present active alarm in delay. | | |
| 3x0081 | Active not tripped alarm no.2 | 0-200 | |
| | Present active alarm in delay. | | |
| 3x0082 | Active not tripped alarm no.3 | 0-200 | |
| | Present active alarm in delay. | | |
| 3x0083 | SA Fan size | 02 - 03 | |
| | Present supply air fan size. | | |
| 3x0084 | EA Fan size | 02 - 03 | |
| | Present extract air fan size. | | |

| | | | |
|---------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|--|
| 3x0085 | Operation mode 1 | 0 - 18,255 | |
| | 0=Manual stop. 1=Ext. stop. 2=Com. stop 1. 3=Manual high speed. 4=Summer night cooling. 5=Int. night heat. 6=Manual low speed. 7=Ext. high speed. 8=Com. high speed. 9=Year channel stop. 10=Year channel high speed. 11=Year channel low speed. 12=Time channel high speed. 13=Ext. low speed. 14=Com. low speed. 15=Time channel low speed. 16=Time channel stop. 17=Low speed=stop. 18=Com. stop 2. 255= | | |
| 3x0086 | Operation mode 2 | 0 - 24 | |
| | 0= 1=Coold air recovery. 2=Cooling boost. 3=SA down regulation. 4=HX defrosting. 5=Anti frost func. active. 6=Effect reduction. 7=Startup. 8=Zero calibration. 9=Extended low speed. 10=Extended high speed. 11=Air adjustment. 12=Cooling off. 13=Purging R.HX. 14=Extended R.HX. op. 15=Filter calibration. 16=R.HX. calibration 17=Morning boost. 18=Heating boost. 19=Alarm. 20=Cooling pressure reduction. 21=Startup extract air fan. 22=Reserve. 23=Airing. 24=Heating. | | |
| 3x0087 | Operation mode, manual | 0 - 3 | |
| | Present manual operation set on the unit's handterminal. 0=Stop. 1=Auto operation. 2=Manual low speed. 3=Manual high speed. | | |
| 3x0088 | Copy of Input Status 1-16. | 0-65535 | |
| | Bit 0=1x0001 Bit 1=1x0002 Bit 15=1x0016 | | |

| | | | |
|---------------|-------------------------------------------------------|-----------|--|
| 3x0089 | Copy of Input Status 17-32. | 0-65535 | |
| | Bit 0=1x00017 Bit 1=1x00018 Bit 15=1x0032 | | |
| 3x0090 | Copy of Input Status 33-48. | 0-65535 | |
| | Bit 0=1x00033 Bit 1=1x00034 Bit 15=1x0048 | | |
| 3x0091 | Heat exchange regulator | 0-100.00% | |
| | Present level of heat exchange regulator. | | |
| 3x0092 | Reserve | | |
| | | | |
| 3x0093 | Reserve | | |
| | | | |
| 3x0094 | Reserve | | |
| | | | |
| 3x0095 | Reserve | | |
| | | | |
| 3x0096 | Reserve | | |
| | | | |
| 3x0097 | Reserve | | |
| | | | |
| 3x0098 | Reserve | | |
| | | | |
| 3x0099 | Reserve | | |
| | | | |
| 3x0100 | Reserve | | |
| | | | |
| 3x0101 | Reserve | | |
| | | | |
| 3x0102 | Reserve | | |
| | | | |
| 3x0103 | Reserve | | |
| | | | |
| 3x0104 | Reserve | | |
| | | | |
| 3x0105 | Reserve | | |
| | | | |
| 3x0106 | R.HX. Efficiency | 0-100.00% | |
| | Calculated level of rotary heat exchanger efficiency. | | |
| 3x0107 | Reserve | | |
| | | | |
| 3x0108 | Reserve | | |
| | | | |
| 3x0109 | Supply air prefilter pressure level | 0-3000Pa | |
| | Present supply air prefilter pressure drop. | | |
| 3x0110 | Supply air prefilter pressure alarm limit. | 0-1000Pa | |
| | Present supply air prefilter pressure alarm limit. | | |

| | | | |
|--------|-------------------------------------------------------------|--------------|--|
| 3x0111 | Supply air prefilter pressure level, new | 0-1000Pa | |
| | Supply air prefilter pressure saved from calibration. | | |
| 3x0112 | Extract air prefilter pressure level | 0-3000Pa | |
| | Present extract air prefilter pressure drop. | | |
| 3x0113 | Extract air prefilter pressure alarm limit. | 0-1000Pa | |
| | Present extract air prefilter pressure alarm limit. | | |
| 3x0114 | Extract air prefilter pressure level, new | 0-1000Pa | |
| | Extract air prefilter pressure saved from calibration. | | |
| 3x0115 | Reserve | | |
| | | | |
| 3x0116 | Reserve | | |
| | | | |
| 3x0117 | Reserve | | |
| | | | |
| 3x0118 | Reserve | | |
| | | | |
| 3x0119 | Reserve | | |
| | | | |
| 3x0120 | Reserve | | |
| | | | |
| 3x0121 | Reserve | | |
| | | | |
| 3x0122 | Reserve | | |
| | | | |
| 3x0123 | Reserve | | |
| | | | |
| 3x0124 | Reserve | | |
| | | | |
| 3x0125 | Pre-heating air temperature | 0.00-40.00°C | |
| | Present pre-heating air temperature. | | |
| 3x0126 | Pre-heating level | 0-100.00% | |
| | Present level of pre-heating. | | |
| 3x0127 | Pre-heating anti frost temperature | 0-40.00°C | |
| | Present anti frost temperature for water pre-heating coils. | | |
| 3x0128 | Reserve | | |
| | | | |
| 3x0129 | Reserve | | |
| | | | |
| 3x0130 | Reserve | | |
| | | | |
| 3x0131 | Reserve | | |
| | | | |
| 3x0132 | Reserve | | |
| | | | |
| 3x0133 | Reserve | | |
| | | | |

| | | | |
|---------------|------------------------------------------------------------------------------------|-----------|--|
| 3x0134 | Preheat operation time | 0-30000 | |
| | Present operation time for preheat, measured in minutes and present in days (24h). | | |
| 3x0135 | Reserve | | |
| | | | |
| 3x0136 | Reserve | | |
| | | | |
| 3x0137 | Demand VOC Level | 0-100.00% | |
| | Present level of demand VOC input. | | |
| 3x0138 | Demand Vin Level | 0-100.00% | |
| | Present level of demand 0-10VDC input. | | |
| 3x0139 | SA Filter level calculated | 0-100.00% | |
| | Present level of calculated supply air filter. | | |
| 3x0140 | EA Filter level calculated | 0-100.00% | |
| | Present level of calculated extract air filter. | | |

Holding Registers. 16-bit integer value (R/W).

| Modbus | Name | Min/Max | Misc |
|--------|-----------------------------------------------------------------------------------------------------------------------------------------------|---------------|------|
| 4x0001 | SA Low speed airflow setpoint | 0-360l/s | |
| | Supply airflow setpoint for the unit when running in low speed operation. | | |
| 4x0002 | SA High speed airflow setpoint | 0-360l/s | |
| | Supply airflow setpoint for the unit when running in high speed operation. | | |
| 4x0003 | SA Max speed airflow setpoint | 0-360l/s | |
| | Supply airflow max. limit for the unit when the low/high speed operation setpoint is altered by boosting function etc. | | |
| 4x0004 | SA Min speed airflow setpoint | 0-360l/s | |
| | Supply airflow min. limit for the unit when the low/high speed operation setpoint is altered when running in fan regulation mode VAV demand. | | |
| 4x0005 | EA Low speed airflow setpoint | 0-360l/s | |
| | Extract airflow setpoint for the unit when running in low speed operation. | | |
| 4x0006 | EA High speed airflow setpoint | 0-360l/s | |
| | Extract airflow setpoint for the unit when running in high speed operation. | | |
| 4x0007 | EA Max speed airflow setpoint | 0-360l/s | |
| | Extract airflow max. limit for the unit when the low/high speed operation setpoint is altered by boosting function etc. | | |
| 4x0008 | EA Min speed airflow setpoint | 0-360l/s | |
| | Extract airflow min. limit for the unit when the low/high speed operation setpoint is altered when running in fan regulation mode VAV demand. | | |
| 4x0009 | SA Low speed pressure setpoint | 0-750Pa | |
| | Supply air duct pressure setpoint for the unit when running in low speed operation. | | |
| 4x0010 | SA High speed pressure setpoint | 0-750Pa | |
| | Supply air duct pressure for the unit when running in high speed operation. | | |
| 4x0011 | SA Max speed output signal | 10.00-100.00% | |
| | Max. limit for the supply air fan speed when running in pressure regulation mode. | | |
| 4x0012 | SA Max speed pressure setpoint | 0-750Pa | |
| | Supply air duct pressure max. limit for the unit when the low/high speed operation setpoint is altered by boosting function etc. | | |
| 4x0013 | EA Low speed pressure setpoint | 0-750Pa | |
| | Extract air duct pressure setpoint for the unit when running in low speed operation. | | |
| 4x0014 | EA High speed pressure setpoint | 0-750Pa | |
| | Extract air duct pressure setpoint for the unit when running in high speed operation. | | |
| 4x0015 | EA Max speed output signal | 10.00-100.00% | |
| | Max. limit for the extract air fan speed when running in pressure regulation mode. | | |

| | | | |
|---------------|---------------------------------------------------------------------------------------------------------------------------------------|-----------------|--|
| 4x0016 | EA Max speed pressure setpoint | 0-750Pa | |
| | Extract air duct pressure max. limit for the unit when the low/high speed operation setpoint is altered by boosting function etc. | | |
| 4x0017 | SA Low speed demand setpoint | 0-100.00% | |
| | Supply air setpoint for the 0-10V input signal on terminal 35..37 for the unit when running in low speed operation. | | |
| 4x0018 | SA High speed demand setpoint | 0-100.00% | |
| | Supply air setpoint for the 0-10V input signal on terminal 35..37 for the unit when running in high speed operation. | | |
| 4x0019 | EA Low speed demand setpoint | 0-100.00% | |
| | Extract air setpoint for the 0-10V input signal on terminal 35..37 for the unit when running in low speed operation. | | |
| 4x0020 | EA High speed demand setpoint | 0-100.00% | |
| | Extract air setpoint for the 0-10V input signal on terminal 35..37 for the unit when running in high speed operation. | | |
| 4x0021 | SA Airflow regulation zone | 1.00 - 10.00 | |
| | Supply airflow regulation zone setting in % of the present airflow setpoint that the regulator is allowed to work within. | | |
| 4x0022 | SA Airflow C-factor | 0.005 - 2.500 | |
| | Supply airflow regulator affection setting. | | |
| 4x0023 | EA Airflow regulation zone | 1.00 - 10.00 | |
| | Extract airflow regulation zone setting in % of the present airflow setpoint that the regulator is allowed to work within. | | |
| 4x0024 | EA Airflow C-factor | 0.005 - 2.500 | |
| | Extract airflow regulator affection setting. | | |
| 4x0025 | SA Pressure regulation zone | 1.00 - 10.00 | |
| | Supply air pressure regulation zone setting in % of the present duct pressure setpoint that the regulator is allowed to work within. | | |
| 4x0026 | SA Pressure C-factor | 0.005 - 2.500 | |
| | Supply air pressure regulator affection setting. | | |
| 4x0027 | EA Pressure regulation zone | 1.00 - 10.00 | |
| | Extract air pressure regulation zone setting in % of the present duct pressure setpoint that the regulator is allowed to work within. | | |
| 4x0028 | EA Pressure C-factor | 0.005 - 2.500 | |
| | Extract air pressure regulator affection setting. | | |
| 4x0029 | SA Demand P-band. | 1.00 - 100.00 | |
| | Supply air demand regulator P-band setting. | | |
| 4x0030 | SA Demand C-factor | 0.005 - 2.500 | |
| | Supply air demand regulator affection setting. | | |
| 4x0031 | EA Demand P-band. | 1.00 - 100.00 | |
| | Extract air demand regulator P-band setting. | | |
| 4x0032 | EA Demand C-factor | 0.005 - 2.500 | |
| | Extract air demand regulator affection setting. | | |
| 4x0033 | ERS 1 Diff | 1.00 - 7.00°C | |
| | Supply air temperature difference setting according to the diagram for ERS 1. | | |
| 4x0034 | ERS 1 Breakpoint | 12.00 - 26.00°C | |
| | Breakpoint setting according to the diagram for ERS 1. | | |

| | | | |
|---------------|----------------------------------------------------------------------------------|---------------|--|
| 4x0035 | ERS 2 Breakpoint X1 | 10.00-38.00°C | |
| | Breakpoint X1 setting according to the diagram for ERS 2. | | |
| 4x0036 | ERS 2 Breakpoint Y1 | 10.00-40.00°C | |
| | Breakpoint Y1 setting according to the diagram for ERS 2. | | |
| 4x0037 | ERS 2 Breakpoint X2 | 11.00-39.00°C | |
| | Breakpoint X2 setting according to the diagram for ERS 2. | | |
| 4x0038 | ERS 2 Breakpoint Y2 | 10.00-40.00°C | |
| | Breakpoint Y2 setting according to the diagram for ERS 2. | | |
| 4x0039 | ERS 2 Breakpoint X3 | 12.00-40.00°C | |
| | Breakpoint X3 setting according to the diagram for ERS 2. | | |
| 4x0040 | ERS 2 Breakpoint Y3 | 10.00-40.00°C | |
| | Breakpoint Y3 setting according to the diagram for ERS 2. | | |
| 4x0041 | SA Temperature setpoint | 10.00-40.00°C | |
| | Supply air temperature setting, for supply air temp regulation mode. | | |
| 4x0042 | EA/Room Temperature setpoint | 10.00-30.00°C | |
| | Extract air/room temperature setting, for Extract air/room temp regulation mode. | | |
| 4x0043 | SA Min temp setpoint | 8.00-20.00°C | |
| | Supply air min.setpoint during EA/room regulation mode. | | |
| 4x0044 | SA Max temp setpoint | 16.00-50.00°C | |
| | Supply air max.setpoint during EA/room regulation mode. | | |
| 4x0045 | SA Temperature P-band | 1.00 - 40.00 | |
| | Supply air temperature regulator P-band setting. | | |
| 4x0046 | EA/Room Temperature P-band | 1.00 - 40.00 | |
| | Extract air/room temperature regulator P-band setting. | | |
| 4x0047 | SA HX. Reg C-factor | 0.000 - 2.500 | |
| | Supply air heat exchange regulator affection setting. | | |
| 4x0048 | EA/Room HX. Reg C-factor | 0.000 - 2.500 | |
| | Extract air/room heat exchange regulator affection setting. | | |
| 4x0049 | SA Heat Reg C-factor | 0.000 - 2.500 | |
| | Supply air reheat regulator affection setting. | | |
| 4x0050 | EA/Room Heat Reg C-factor | 0.000 - 2.500 | |
| | Extract air/room reheat regulator affection setting. | | |
| 4x0051 | Reserve | | |
| | | | |
| 4x0052 | Reserve | | |
| | | | |
| 4x0053 | Reserve | | |
| | | | |
| 4x0054 | Reserve | | |
| | | | |

| | | | |
|---------------|----------------------------------------------------------------|---------------|--|
| 4x0055 | SA Down regulation Reg C-factor | 0.000 - 2.500 | |
| | Supply air reheat regulator affection setting. | | |
| 4x0056 | Reserve | | |
| | | | |
| 4x0057 | SA Cool reg C-factor | 0.000 - 2.500 | |
| | Supply air cool regulator affection setting. | | |
| 4x0058 | EA/Room Cool reg C-factor | 0.000 - 2.500 | |
| | Extract air/room cool regulator affection setting. | | |
| 4x0059 | SA Cooling boost C-factor | 0.000 - 2.500 | |
| | Supply air cooling boost affection setting. | | |
| 4x0060 | EA/Room Cooling boost reg C-factor | 0.000 - 2.500 | |
| | Extract air/room cooling boost regulator affection setting. | | |
| 4x0061 | HX Pressure alarm set. | 30 - 100Pa | |
| | Heat exchange pressure alarm limit setting (alarm no.38). | | |
| 4x0062 | Reserve | | |
| | | | |
| 4x0063 | Reserve | | |
| | | | |
| 4x0064 | Cooling off set. | 10 - 50% | |
| | Cooling off airflow setting in % of max. airflow. | | |
| 4x0065 | SA Down regulation neutral zone | 0.00-10.00°C | |
| | Neutral zone setting before downregulation is permitted. | | |
| 4x0066 | Cool Outdoor temp limit.1 | 0.00-25.00°C | |
| | Outdoor temperature limit setting for cooling stage 1. | | |
| 4x0067 | Cool Outdoor temp limit.2 | 0.00-25.00°C | |
| | Outdoor temperature limit setting for cooling stage 2. | | |
| 4x0068 | Cool Outdoor temp limit.3 | 0.00-25.00°C | |
| | Outdoor temperature limit setting for cooling stage 3. | | |
| 4x0069 | Temperature reg. Neutral zone | 0.50-10.00°C | |
| | Neutral zone setting before shift between heating and cooling. | | |
| 4x0070 | SA Cool min air flow | 0-360l/s | |
| | Supply air min. air flow setting for cooling. | | |
| 4x0071 | EA Cool min air flow | 0-360l/s | |
| | Extract air min. air flow setting for cooling. | | |
| 4x0072 | Heating boost start limit | 2.00-10.00°C | |
| | Heating boost start temperature limit. | | |
| 4x0073 | Cooling boost start limit | 2.00-10.00°C | |
| | Cooling boost (comfort) start temperature limit. | | |
| 4x0074 | SA Filter alarm limit | 0-1000Pa | |
| | Supply air filter pressure alarm limit setting. | | |

| | | | |
|---------------|---------------------------------------------------------------------------------------|-------------------|--|
| 4x0075 | EA Filter alarm limit | 0-1000Pa | |
| | Extract air filter pressure alarm limit setting. | | |
| 4x0076 | Int. Night heat room start temp | 5.00-40.00°C | |
| | Intermittent night heat function, extract air temperature setting for start. | | |
| 4x0077 | Int. Night heat room stop temp | 5.00-40.00°C | |
| | Intermittent night heat function, extract air temperature setting for stop. | | |
| 4x0078 | Int. Night heat SA temp setpoint | 5.00-40.00°C | |
| | Intermittent night heat function, supply air temperature setpoint during night heat. | | |
| 4x0079 | Int. Night heat SA airflow setpoint | 0-360l/s | |
| | Intermittent night heat function, supply airflow setpoint during night heat. | | |
| 4x0080 | Int. Night heat EA airflow setpoint | 0-360l/s | |
| | Intermittent night heat function, extract airflow setpoint during night heat. | | |
| 4x0081 | Summer night cool EA start temp | 17.00-27.00°C | |
| | Summer night cool function, extract air temperature setting for start. | | |
| 4x0082 | Summer night cool EA stop temp | 12.00-22.00°C | |
| | Summer night cool function, extract air temperature setting for stop. | | |
| 4x0083 | Summer night cool outdoor temp limit | 5.00-15.00°C | |
| | Summer night cool function, outdoor temperature limit. | | |
| 4x0084 | Summer night cool SA temp setpoint | 10.00-20.00°C | |
| | Summer night cool function, supply air temperature setpoint during summer night cool. | | |
| 4x0085 | Outdoor temp comp. Winter X1. | -30.00-(-10.00)°C | |
| | Endpoint of winter compensation. | | |
| 4x0086 | Outdoor temp comp. Winter X2. | -10.00-15.00°C | |
| | Startpoint of winter compensation. | | |
| 4x0087 | Outdoor temp comp. Winter Y1. | 0.00-10.00°C | |
| | Level of winter compensation at X1. | | |
| 4x0088 | Outdoor temp comp. Summer X3. | 15.00-25.00°C | |
| | Startpoint of summer compensation. | | |
| 4x0089 | Outdoor temp comp. Summer X4. | 25.00-40.00°C | |
| | Endpoint of summer compensation. | | |
| 4x0090 | Outdoor temp comp. Summer Y2. | -10.00-10.00°C | |
| | Level of summer compensation at X4. | | |
| 4x0091 | Outdoor airflow comp. Winter X1. | -30.00-(-10.00)°C | |
| | Endpoint of winter compensation. | | |
| 4x0092 | Outdoor airflow comp. Winter X2. | -10.00-15.00°C | |
| | Startpoint of winter compensation. | | |
| 4x0093 | Outdoor airflow comp. Winter Y1. | 0-50.00% | |
| | Level of airflow compensation at X1. | | |
| 4x0094 | Reserve | | |
| | | | |

| | | | |
|---------------|------------------------------------------------------------------------------------------------------------------------------------------------|--------------|--|
| 4x0095 | EA/Room min temp alarm limit | 8.00-20.00°C | |
| | Setting for min extract air /room temp alarm no.40. | | |
| 4x0096 | SA Deviation alarm limit | 2.00-15.00°C | |
| | Setting for supply air temperature below present setpoint, alarm no.41. | | |
| 4x0097 | Reserve | | |
| | | | |
| 4x0098 | SA Fan regulation mode | 0 - 3 | |
| | Setting of regulation type for the supply air fan. 0=Airflow reg. 1=Pressure reg. 2=Demand reg. 3=Slave controlled by EA fan. | | |
| 4x0099 | EA Fan regulation mode | 0 - 3 | |
| | Setting of regulation type for the extract air fan. 0=Airflow reg. 1=Pressure reg. 2=Demand reg. 3=Slave controlled by SA fan. | | |
| 4x0100 | ERS Step | 1 - 4 | |
| | Setting of curve when temperature is above breakpoint. | | |
| 4x0101 | Temperature regulation mode. | 0 - 3 | |
| | Setting of temperature regulation type. 0=ERS 1 reg. 1=ERS 2 reg. 2=SA reg. 3=EA/Room reg. | | |
| 4x0102 | Cooling off periode | 60 - 1500s | |
| | Time setting for cooling off electrical heating coil. | | |
| 4x0103 | Cool step time | 0 - 600s | |
| | Time setting between cool step shift. | | |
| 4x0104 | Cool restart time | 60 - 900s | |
| | Setting of time between two starts of the cool relays. | | |
| 4x0105 | Cool regulation mode | 0 - 4 | |
| | Setting of cool regulation type 0=Controlled 0-10V 1=Controlled 10-0V 2=On/Off 1-step 3=On/Off 2-steps 4=On/Off 3-steps binary | | |
| 4x0106 | Heating boost regulation mode. | 0 - 1 | |
| | Setting for heating boost function. 0=Inactive. 1=Active. | | |
| 4x0107 | Cooling boost regulation mode. | 0 - 5 | |
| | Setting of cooling boost regulation type. 0=Inactive. 1=Comfort. 2=Economy. 3=Sequence. 4=Comfort+economy 5=Economy+sequence | | |

| | | | |
|---------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|--|
| 4x0108 | Filter calibration mode | 0 - 4 | |
| | Setting for required filtercalibration. 0=Inactive. 1=SA+EA-Filter. 2=SA-Filter. 3=EA-Filter. 4=HX. | | |
| 4x0109 | Air adjustment time, minutes | 0 - 1728 | |
| | Setting for amount of minutes to air adjustment function. | | |
| 4x0110 | Air adjustment time, hours | 0 - 72 | |
| | Setting for amount of hours to air adjustment function. | | |
| 4x0111 | Handterminal language | 0 - 18 | |
| | 0=Svenska 1=Norsk 2=Dansk 3=Suomi 4=English 5=Francaise 6=Deutsch 7=Polski 8=Cesky 9=Italiano 10=Espanol 11=Portugues 12=Русский 13=Eesti 14=Latviesu 15=Lietiviu 16=Nederlands 17=Hungarian 18=Turkce | | |
| 4x0112 | Summer night cool start, hour | 0-23 | |
| | Setting for start time of summer night cooling function. | | |
| 4x0113 | Summer night cool start, minute | 0-59 | |
| | Setting for start time of summer night cooling function. | | |
| 4x0114 | Summer night cool stop, hour | 0-23 | |
| | Setting for stop time of summer night cooling function. | | |
| 4x0115 | Summer night cool stop, minute | 0-59 | |
| | Setting for stop time of summer night cooling function. | | |
| 4x0116 | Reserve | | |
| | | | |
| 4x0117 | Reserve | | |
| | | | |
| 4x0118 | Morning boost time, hours | 0-23 | |
| | Setting of morning boost time before normal operation. | | |
| 4x0119 | Morning boost time, minutes | 0-59 | |
| | Setting of morning boost time before normal operation. | | |
| 4x0120 | Startup time | 0 - 600s | |
| | Setting of time for startup when the unit regulator is running with fixed signals. | | |
| 4x0121 | Start delay SA fan. | 0 - 600s | |
| | Setting of start delay time for the supply air fan. | | |

| | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|----------------|------------|-------------|----------|-----------|-----------|------------|-------------|--------------|-------------|-------------|----------|-----------|------------|-------------|----------|-----------|------------------|-------------------|------------------|-------------------|---------------------|---------------------|--|--|
| 4x0122 | Start delay EA fan. | 0 - 600s | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Setting of start delay time for the extract air fan after supply air fan has started. | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0123 | Air flow unit | 0 -2 | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Setting of air flow unit presented in the unit's handterminal and WEB. 0=l/s. 1=m3/s. 2=m3/h. | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0124 | Reserve | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0125 | Year | 2000-2100 | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Setting for the unit's internal clock. | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0126 | Month | 1-12 | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Setting for the unit's internal clock. | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0127 | Date | 0-31 | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Setting for the unit's internal clock. | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0128 | Hour | 0-23 | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Setting for the unit's internal clock. | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0129 | Minute | 0-59 | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Setting for the unit's internal clock. | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0130 | Second | 0-59 | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Setting for the unit's internal clock. | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0131 | Time channel 1 status | 0-10,16-26 | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <table border="0"> <tr> <td>Low speed</td> <td>Högfart</td> </tr> <tr> <td>0=Deactive</td> <td>16=Deactive</td> </tr> <tr> <td>1=Monday</td> <td>17=Monday</td> </tr> <tr> <td>2=Tuesday</td> <td>18=Tuesday</td> </tr> <tr> <td>3=Wednesday</td> <td>19=Wednesday</td> </tr> <tr> <td>4=Thursday.</td> <td>20=Thursday</td> </tr> <tr> <td>5=Friday</td> <td>21=Friday</td> </tr> <tr> <td>6=Saturday</td> <td>22=Saturday</td> </tr> <tr> <td>7=Sunday</td> <td>23=Sunday</td> </tr> <tr> <td>8=Monday..Friday</td> <td>24=Monday..Friday</td> </tr> <tr> <td>9=Monday..Sunday</td> <td>25=Monday..Sunday</td> </tr> <tr> <td>10=Saturday..Sunday</td> <td>26=Saturday..Sunday</td> </tr> </table> | Low speed | Högfart | 0=Deactive | 16=Deactive | 1=Monday | 17=Monday | 2=Tuesday | 18=Tuesday | 3=Wednesday | 19=Wednesday | 4=Thursday. | 20=Thursday | 5=Friday | 21=Friday | 6=Saturday | 22=Saturday | 7=Sunday | 23=Sunday | 8=Monday..Friday | 24=Monday..Friday | 9=Monday..Sunday | 25=Monday..Sunday | 10=Saturday..Sunday | 26=Saturday..Sunday | | |
| Low speed | Högfart | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0=Deactive | 16=Deactive | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1=Monday | 17=Monday | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2=Tuesday | 18=Tuesday | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3=Wednesday | 19=Wednesday | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4=Thursday. | 20=Thursday | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5=Friday | 21=Friday | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6=Saturday | 22=Saturday | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7=Sunday | 23=Sunday | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8=Monday..Friday | 24=Monday..Friday | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9=Monday..Sunday | 25=Monday..Sunday | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10=Saturday..Sunday | 26=Saturday..Sunday | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0132 | Time channel 1 start hour | 0-23 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0133 | Time channel 1 start minute | 0-59 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0134 | Time channel 1 stop hour | 0-23 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0135 | Time channel 1 stop minute | 0-59 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0136 | Time channel 2 status | 0-10,16-26 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0137 | Time channel 2 start hour | 0-23 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0138 | Time channel 2 start minute | 0-59 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0139 | Time channel 2 stop hour | 0-23 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0140 | Time channel 2 stop minute | 0-59 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0141 | Time channel 3 status | 0-10,16-26 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0142 | Time channel 3 start hour | 0-23 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0143 | Time channel 3 start minute | 0-59 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0144 | Time channel 3 stop hour | 0-23 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0145 | Time channel 3 stop minute | 0-59 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4x0146 | Time channel 4 status | 0-10,16-26 | | | | | | | | | | | | | | | | | | | | | | | | | |

| | | | |
|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|--|
| 4x0147 | Time channel 4 start hour | 0-23 | |
| 4x0148 | Time channel 4 start minute | 0-59 | |
| 4x0149 | Time channel 4 stop hour | 0-23 | |
| 4x0150 | Time channel 4 stop minute | 0-59 | |
| 4x0151 | Time channel 5 status | 0-10,16-26 | |
| 4x0152 | Time channel 5 start hour | 0-23 | |
| 4x0153 | Time channel 5 start minute | 0-59 | |
| 4x0154 | Time channel 5 stop hour | 0-23 | |
| 4x0155 | Time channel 5 stop minute | 0-59 | |
| 4x0156 | Time channel 6 status | 0-10,16-26 | |
| 4x0157 | Time channel 6 start hour | 0-23 | |
| 4x0158 | Time channel 6 start minute | 0-59 | |
| 4x0159 | Time channel 6 stop hour | 0-23 | |
| 4x0160 | Time channel 6 stop minute | 0-59 | |
| 4x0161 | Time channel 7 status | 0-10,16-26 | |
| 4x0162 | Time channel 7 start hour | 0-23 | |
| 4x0163 | Time channel 7 start minute | 0-59 | |
| 4x0164 | Time channel 7 stop hour | 0-23 | |
| 4x0165 | Time channel 7 stop minute | 0-59 | |
| 4x0166 | Time channel 8 status | 0-10,16-26 | |
| 4x0167 | Time channel 8 start hour | 0-23 | |
| 4x0168 | Time channel 8 start minute | 0-59 | |
| 4x0169 | Time channel 8 stop hour | 0-23 | |
| 4x0170 | Time channel 8 stop minute | 0-59 | |
| 4x0171 | Extended low speed op. Hours | 0-23 | |
| | Setting for extended low speed operation. | | |
| 4x0172 | Extended low speed op. Minutes | 0-59 | |
| | Setting for extended low speed operation. | | |
| 4x0173 | Extended high speed op. Hours | 0-23 | |
| | Setting for extended low speed operation. | | |
| 4x0174 | Extended high speed op. Minutes | 0-59 | |
| | Setting for extended low speed operation. | | |
| 4x0175 | Communication operation mode | 0 - 4 | |
| | Setting of unit operation mode from communication. 0=Auto operation. 1=Communication stop 1. 2=Communication low speed. 3=Communication high speed. 4=Communication stop 2 Summer night cool, intermittent night heat and morning boost functions works at stop 2. | | |
| 4x0176 | Service periode alarm. | 0-99 | |
| | Setting for delay time in months before service alarm. | | |
| 4x0177 | External alarm 1 delay | 1 - 600s | |
| | Setting of delay time for external alarm no 1 | | |
| 4x0178 | External alarm 2 delay | 1 - 600s | |
| | Setting of delay time for external alarm no 2 | | |

| | | | |
|--------|-----------------------------------------------------------------------------------|---------------|--|
| 4x0179 | Int. Night heat SA pressure setpoint | 20-750Pa | |
| | Intermittent night heat function, supply pressure setpoint during night heat. | | |
| 4x0180 | Int. Night heat EA pressure setpoint | 20-750Pa | |
| | Intermittent night heat function, extract pressure setpoint during night heat. | | |
| 4x0181 | Copy of Coil Status 1-16 | 0-65535 | |
| | Bit 0=1x0001 Bit 1=1x0002 Bit 15=1x0016 | | |
| 4x0182 | Copy of Coil Statust 17-32 | 0-65535 | |
| | Bit 0=1x00017 Bit 1=1x00018 Bit 15=1x0032 | | |
| 4x0183 | Copy of Coil Status 33-48 | 0-65535 | |
| | Bit 0=1x00033 Bit 1=1x00034 Bit 15=1x0048 | | |
| 4x0184 | Heat relay periodic func. | 0-3 | |
| | Setting of periodic operation. 0=Inactive 1=Pump 2=Pump+valve 3=Valve | | |
| 4x0185 | Cool relay 1 periodic func. | 0-3 | |
| | Setting of periodic operation. 0=Inactive 1=Pump 2=Pump+valve 3=Valve | | |
| 4x0186 | Cool relay 2 periodic func. | 0-3 | |
| | Setting of periodic operation. 0=Inactive 1=Pump 2=Pump+valve 3=Valve | | |
| 4x0187 | Slave control C-factor | 0.500 - 1.500 | |
| | Slave regulator affection setting. | | |
| 4x0188 | Reserve | | |
| 4x0189 | Reserve | | |
| 4x0190 | Reserve | | |
| 4x0191 | Reserve | | |
| 4x0192 | Reserve | | |
| 4x0193 | Reserve | | |
| 4x0194 | Reserve | | |

| | | | |
|---------------|------------------------------------------------------------------------------------------------------------------|-----------------|--|
| 4x0195 | Reserve | | |
| 4x0196 | Water heating periodic op. time | 0-60min | |
| | Setting of periodic op. time (minute). | | |
| 4x0197 | Water heating interval | 0-168h | |
| | Setting of water heating interval time (hour). | | |
| 4x0198 | Cool periodic op. time | 0-60min | |
| | Setting of periodic op. time (minute). | | |
| 4x0199 | Cool interval | 0-168h | |
| | Setting of cool interval time (hour). | | |
| 4x0200 | Reserve | | |
| 4x0201 | EA/Room temperature (external) func. | 0-2 | |
| | Setting of EA/Room temperature (external) function. 0= Inactive. 1= IQnomic. 2= Communication (4x0202). | | |
| 4x0202 | EA/Room temperature com. | -55.00-125.00°C | |
| | Setting of EA/Room temperature via communication. | | |
| 4x0203 | Outdoor temperature (external) func. | 0-2 | |
| | Setting of outdoor temperature (external) function. 0= Inactive. 1= IQnomic. 2= Communication (4x0204). | | |
| 4x0204 | Outdoor temperature com. | -55.00-125.00°C | |
| | Setting of outdoor temperature via communication. | | |
| 4x0205 | Timeout temperature com. | 0-9999min | |
| | Setting of timeout for temperature via communication (4x0202, 4x0204). | | |
| 4x0206 | Flow at fire function. | 0-3 | |
| | Setting for activating the air fan operation at fire function 0= Inactive. 1= SA. 2= EA. 3= SA+EA. | | |
| 4x0207 | Air fan down regulation func. | 0-2 | |
| | Setting for activating the air fan down regulation function 0= Inactive. 1= SA. 2= SA+EA. | | |
| 4x0208 | SA speed at fire. | 10.00-100.00% | |
| | Setting of supply air speed at fire. | | |
| 4x0209 | EA speed at fire. | 10.00-100.00% | |
| | Setting of extract air speed at fire. | | |
| 4x0210 | Reserve | | |
| 4x0211 | Reserve | | |
| 4x0212 | Supply air min P-band. | 1.00 - 40.00 | |
| | Supply air min regulator P-band setting. | | |

| | | | |
|--------|-----------------------------------------------------------------|---------------|--|
| 4x0213 | Supply air min C-factor. | 0.000 - 2.500 | |
| | Supply air min regulator affection setting. | | |
| 4x0214 | Supply air max P-band. | 1.00 - 40.00 | |
| | Supply air max regulator P-band setting. | | |
| 4x0215 | Supply air max C-factor. | 0.000 - 2.500 | |
| | Supply air max regulator affection setting. | | |
| 4x0216 | Year channel 1 function. | 0 - 3 | |
| | 0 = Inactive. 1 = Stop. 2 = Low speed. 3 = High speed. | | |
| 4x0217 | Year channel 1 start year. | 2000 - 2099 | |
| 4x0218 | Year channel 1 start month. | 1 - 12 | |
| 4x0219 | Year channel 1 start date. | 1 - 31 | |
| 4x0220 | Year channel 1 start hour. | 0 - 23 | |
| 4x0221 | Year channel 1 start minute. | 0 - 59 | |
| 4x0222 | Year channel 1 stop year. | 2000 - 2099 | |
| 4x0223 | Year channel 1 stop month. | 1 - 12 | |
| 4x0224 | Year channel 1 stop date. | 1 - 31 | |
| 4x0225 | Year channel 1 stop hour. | 0 - 23 | |
| 4x0226 | Year channel 1 stop minute. | 0 - 59 | |
| 4x0227 | Year channel 2 function. | 0 - 3 | |
| 4x0228 | Year channel 2 start year. | 2000 - 2099 | |
| 4x0229 | Year channel 2 start month. | 1 - 12 | |
| 4x0230 | Year channel 2 start date. | 1 - 31 | |
| 4x0231 | Year channel 2 start hour. | 0 - 23 | |
| 4x0232 | Year channel 2 start minute. | 0 - 59 | |
| 4x0233 | Year channel 2 stop year. | 2000 - 2099 | |
| 4x0234 | Year channel 2 stop month. | 1 - 12 | |
| 4x0235 | Year channel 2 stop date. | 1 - 31 | |
| 4x0236 | Year channel 2 stop hour. | 0 - 23 | |
| 4x0237 | Year channel 2 stop minute. | 0 - 59 | |
| 4x0238 | Year channel 3 function. | 0 - 3 | |
| 4x0239 | Year channel 3 start year. | 2000 - 2099 | |
| 4x0240 | Year channel 3 start month. | 1 - 12 | |
| 4x0241 | Year channel 3 start date. | 1 - 31 | |
| 4x0242 | Year channel 3 start hour. | 0 - 23 | |
| 4x0243 | Year channel 3 start minute. | 0 - 59 | |
| 4x0244 | Year channel 3 stop year. | 2000 - 2099 | |
| 4x0245 | Year channel 3 stop month. | 1 - 12 | |
| 4x0246 | Year channel 3 stop date. | 1 - 31 | |
| 4x0247 | Year channel 3 stop hour. | 0 - 23 | |
| 4x0248 | Year channel 3 stop minute. | 0 - 59 | |
| 4x0249 | Year channel 4 function. | 0 - 3 | |
| 4x0250 | Year channel 4 start year. | 2000 - 2099 | |
| 4x0251 | Year channel 4 start month. | 1 - 12 | |
| 4x0252 | Year channel 4 start date. | 1 - 31 | |
| 4x0253 | Year channel 4 start hour. | 0 - 23 | |

| | | | |
|--------|------------------------------|-------------|--|
| 4x0254 | Year channel 4 start minute. | 0 - 59 | |
| 4x0255 | Year channel 4 stop year. | 2000 - 2099 | |
| 4x0256 | Year channel 4 stop month. | 1 - 12 | |
| 4x0257 | Year channel 4 stop date. | 1 - 31 | |
| 4x0258 | Year channel 4 stop hour. | 0 - 23 | |
| 4x0259 | Year channel 4 stop minute. | 0 - 59 | |
| 4x0260 | Year channel 5 function. | 0 - 3 | |
| 4x0261 | Year channel 5 start year. | 2000 - 2099 | |
| 4x0262 | Year channel 5 start month. | 1 - 12 | |
| 4x0263 | Year channel 5 start date. | 1 - 31 | |
| 4x0264 | Year channel 5 start hour. | 0 - 23 | |
| 4x0265 | Year channel 5 start minute. | 0 - 59 | |
| 4x0266 | Year channel 5 stop year. | 2000 - 2099 | |
| 4x0267 | Year channel 5 stop month. | 1 - 12 | |
| 4x0268 | Year channel 5 stop date. | 1 - 31 | |
| 4x0269 | Year channel 5 stop hour. | 0 - 23 | |
| 4x0270 | Year channel 5 stop minute. | 0 - 59 | |
| 4x0271 | Year channel 6 function. | 0 - 3 | |
| 4x0272 | Year channel 6 start year. | 2000 - 2099 | |
| 4x0273 | Year channel 6 start month. | 1 - 12 | |
| 4x0274 | Year channel 6 start date. | 1 - 31 | |
| 4x0275 | Year channel 6 start hour. | 0 - 23 | |
| 4x0276 | Year channel 6 start minute. | 0 - 59 | |
| 4x0277 | Year channel 6 stop year. | 2000 - 2099 | |
| 4x0278 | Year channel 6 stop month. | 1 - 12 | |
| 4x0279 | Year channel 6 stop date. | 1 - 31 | |
| 4x0280 | Year channel 6 stop hour. | 0 - 23 | |
| 4x0281 | Year channel 6 stop minute. | 0 - 59 | |
| 4x0282 | Year channel 7 function. | 0 - 3 | |
| 4x0283 | Year channel 7 start year. | 2000 - 2099 | |
| 4x0284 | Year channel 7 start month. | 1 - 12 | |
| 4x0285 | Year channel 7 start date. | 1 - 31 | |
| 4x0286 | Year channel 7 start hour. | 0 - 23 | |
| 4x0287 | Year channel 7 start minute. | 0 - 59 | |
| 4x0288 | Year channel 7 stop year. | 2000 - 2099 | |
| 4x0289 | Year channel 7 stop month. | 1 - 12 | |
| 4x0290 | Year channel 7 stop date. | 1 - 31 | |
| 4x0291 | Year channel 7 stop hour. | 0 - 23 | |
| 4x0292 | Year channel 7 stop minute. | 0 - 59 | |
| 4x0293 | Year channel 8 function. | 0 - 3 | |
| 4x0294 | Year channel 8 start year. | 2000 - 2099 | |
| 4x0295 | Year channel 8 start month. | 1 - 12 | |
| 4x0296 | Year channel 8 start date. | 1 - 31 | |
| 4x0297 | Year channel 8 start hour. | 0 - 23 | |
| 4x0298 | Year channel 8 start minute. | 0 - 59 | |
| 4x0299 | Year channel 8 stop year. | 2000 - 2099 | |
| 4x0300 | Year channel 8 stop month. | 1 - 12 | |

| | | | |
|--------|------------------------------------------------------------------------------------------------------------|-----------|--|
| 4x0301 | Year channel 8 stop date. | 1 - 31 | |
| 4x0302 | Year channel 8 stop hour. | 0 - 23 | |
| 4x0303 | Year channel 8 stop minute. | 0 - 59 | |
| 4x0304 | Filter select. | 0 - 3 | |
| | Setting for filter select function. 0=Inactive. 1=Supply air. 2=Extract air. 3=SA+EA. | | |
| 4x0305 | Prefilter select. | 0 - 3 | |
| | Setting for prefilter select function. 0=Inactive. 1=Supply air. 2=Extract air. 3=SA+EA. | | |
| 4x0306 | SA prefilter alarm limit. | 10-1000Pa | |
| | Supply air prefilter pressure alarm limit setting. | | |
| 4x0307 | EA prefilter alarm limit. | 10-1000Pa | |
| | Extract air prefilter pressure alarm limit setting. | | |
| 4x0308 | Prefilter calibration mode. | 0 - 3 | |
| | Setting for requiered filtercalibration. 0=Inactive. 1=SA+EA-Filter. 2=SA-Filter. 3=EA-Filter. | | |
| 4x0309 | Reserve | | |
| | | | |
| 4x0310 | Reserve | | |
| | | | |
| 4x0311 | Reserve | | |
| | | | |
| 4x0312 | Reserve | | |
| | | | |
| 4x0313 | Reserve | | |
| | | | |
| 4x0314 | Reserve | | |
| | | | |
| 4x0315 | Reserve | | |
| | | | |
| 4x0316 | Reserve | | |
| | | | |
| 4x0317 | Reserve | | |
| | | | |
| 4x0318 | Reserve | | |
| | | | |
| 4x0319 | Reserve | | |
| | | | |
| 4x0320 | Reserve | | |
| | | | |
| 4x0321 | Reserve | | |
| | | | |

| | | | |
|--------|---------------------------------------------------------------------------------------------------------------------------------------------|----------------|--|
| 4x0322 | Reserve | | |
| 4x0323 | Reserve | | |
| 4x0324 | Reserve | | |
| 4x0325 | Reserve | | |
| 4x0326 | Preheating function. | 0 - 4 | |
| | Setting of preheating function. 0=Inactive. 1=El. coil P/P. 2=El. coil 0-10V. 3=Water coil with FP. 4=Water coil without FP. | | |
| 4x0327 | Preheating setpoint. | -30.00-30.00°C | |
| | Setting of preheating temperature setpoint. | | |
| 4x0328 | Reserve | | |
| 4x0329 | Reserve | | |
| 4x0330 | Reserve | | |
| 4x0331 | Reserve | | |
| 4x0332 | Reserve | | |
| 4x0333 | Reserve | | |
| 4x0334 | Reserve | | |
| 4x0335 | Reserve | | |
| 4x0336 | Reserve | | |
| 4x0337 | Preheat P-band. | 1.00 - 40.00 | |
| | Preheat regulator P-band setting. | | |
| 4x0338 | Preheat C-factor. | 0.000 - 2.500 | |
| | Preheat regulator affection setting. | | |
| 4x0339 | Reserve | | |
| 4x0340 | Reserve | | |
| 4x0341 | Reserve | | |
| 4x0342 | Reserve | | |
| 4x0343 | Reserve | | |

| | | | |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------|--|
| 4x0344 | Reserve | | |
| 4x0345 | Reserve | | |
| 4x0346 | Reserve | | |
| 4x0347 | Reserve | | |
| 4x0348 | Reserve | | |
| 4x0349 | Reserve | | |
| 4x0350 | SA Filter calculated alarm level | 5.00-20.00% | |
| | Supply air filter calculated alarm limit setting. | | |
| 4x0351 | EA Filter calculated alarm level | 5.00-20.00% | |
| | Extract air filter calculated alarm limit setting. | | |
| 4x0352 | Mode digital output relay 1 | 0-8 | |
| | Setting of mode output relay 1 function. 0=Damper. 1=Operation. 2=Low speed. 3=High speed. 4=Alarm A. 5=Alarm B. 6=Heating. 7=Cooling 1. 8=Cooling 2. | | |
| 4x0353 | Mode digital output relay 2 | 0-8 | |
| | Setting of mode output relay 2 function. 0=Damper. 1=Operation. 2=Low speed. 3=High speed. 4=Alarm A. 5=Alarm B. 6=Heating. 7=Cooling 1. 8=Cooling 2. | | |
| 4x0354 | Mode digital input 1 | 0-6 | |
| | Setting of mode input 1 function. 0=Stop. 1=Low speed. 2=High speed. 3=Alarm 1. 4=Alarm 2. 5=Reset. 6=Fire. | | |

| | | | |
|---------------|-----------------------------------------------------------------------------------------------------------------------------------------|-------------|--|
| 4x0355 | Mode digital input 2 | 0-6 | |
| | Setting of mode input 2 function. 0=Stop. 1=Low speed. 2=High speed. 3=Alarm 1. 4=Alarm 2. 5=Reset. 6=Fire. | | |
| 4x0356 | Manual morning boost time hour | 0-23 | |
| | Setting of manual morning boost time before normal operation. | | |
| 4x0357 | Manual morning boost time minutes | 0-59 | |
| | Setting of manual morning boost time before normal operation. | | |
| 4x0358 | Airing temp set | 10.00-20.00 | |
| | Setting of airing temperature setpoint. | | |
| 4x0359 | Airing time set | 10-60 | |
| | Setting of airing time in minutes. | | |
| 4x0360 | Manual operation drift mode | 0-4 | |
| | Setting of manual operation drift mode. 0=Normal operation. 1=Extended operation. 2=Airing. 3=Heating. 4=Heating+Recirc. | | |

